
Пульт дистанционного управления универсальный

ДУ-14 Ж

TYPE: D007B001

TOSHIBA



Описание:

Заменяет пульты ДУ Toshiba:

CT-3200; CT-9430; CT-9859; CT-3700;
CT-9507; CT-9878; CT-4900; CT-9510;
CT-9879; CT-5300; CT-9584; CT-9880;
CT-5700; CT-9640; CT-9881; CT-5900;
CT-9712; CT-9922; CT-7140; CT-9725;
CT-9942; CT-7180; CT-9734; CT-9992;
CT-8010; CT-9737; ST-046C; CT-8002;
CT-9782; ST-046AC; CT-841; CT-9806;
ST-046P; CT-861; CT-9810; ST-046AP;
CT-90004; CT-9818; CT-10000;
CT-90119; CT-9843; K34T-007(008);
CT-90142; CT-9844; RM-003; CT-90163;
CT-9851; RM-162B; CT-9199; CT-9852;
CT-9347; CT-9854; CT-9369; CT-9856;
CT-9396; CT-9858;